

HG[®]

OUTDOORS

garden furniture cleaner

extremely powerful



500 ml e

HG garden furniture cleaner

- extremely powerful
- for all types of garden furniture

HG garden furniture cleaner effortlessly removes stubborn stains from plastic, aluminium, woven cane (look), pulp cane, polywood and metal garden furniture, as well as from epoxy, galvanised and most other (combinations of) materials.

Directions for use: Turn the nozzle on the front side a quarter. Spray the surface area to be cleaned and leave to soak for one to two minutes. Remove dirt with a cloth or kitchen roll. For very stubborn stains, leave to soak a little longer. Remove dirt with a brush or a pad and rinse. Turn the nozzle a quarter after use (OFF).

Attention: Transport and store the bottle upright. For weathered plastic furniture we recommend *HG plastic garden furniture restorer*. For maintenance of your (hard) wood garden furniture, please refer to our extensive product range for hardwood products. **P101-** If medical advice is needed, have product container or label at hand. **P102-** Keep out of reach of children.


Medical personnel can request the data-sheet via +31 36 54 94 777
The consumer's information sheet can be obtained via www.HG.eu



contains a.o.:	
non-ionic and anionic surfactants, phosphates	< 5%
preservation agents: 2-bromo-2-nitropropane-1,3-diol	

Made in The Netherlands by HG International b.v.,
P.J. Oudweg 41, 1314 CJ Almere, The Netherlands,
Tel.: +31 36 54 94 700

UK importer: HG UKI Ltd,
Weston Business Centre, Parsonage Road, Takeley,
Essex, CM22 6PU. Tel.: +44 (0) 1206 822 744



0512400105006
2309

Products and tips? See:

HG.EU

Consumer Services?
Call: +44 (0)1279 598360

HG Does what it promises.