

grout cleaner

concentrate



HG grout cleaner concentrate

• restores the colour of the grout

HG grout cleaner concentrate is a buffered, synthetic cleaning agent. These properties mean it continues to work at the same powerful level whilst it is left to work and during scrubbing afterwards. HG grout cleaner can be used on different types of grout between wall tiles, floor tiles and bricks.

Directions for use: Dilute HG grout cleaner concentrate 1:4 in lukewarm water. Apply the solution to grout joints with a brush or scrubbing sponge. Leave to work for approx. 10 minutes then scrub the grout with the brush or scrubbing sponge. Finally clean with lukewarm water to remove the dirt (it is important to clean the sponge repeatedly in clean water). Leave to dry. If necessary repeat the application. Discoloration of grout in shower cubicles and bathrooms is often caused by limescale, in which case HG limescale remover concentrate should be used. For grout that has become black (mould) use HG mould spray.

Coverage: 0,5 litre is sufficient for 10-15 m^2 tiled surface.

Attention: Transport and store the bottle upright. It is recommended to test this product in an inconspicuous place first. Not suitable for gloss surfaces, surfaces that are sensitive to acids, or grout treated with gloss paint. Not to be used on grout of lime-containing tiles (as marble etc.). The results may not be optimum on silicon grouting.

Medical personnel can request the data sheet via +31 36 54 94 777

The consumer's information sheet can be obtained via www.HG.eu



0513501105006 2201





contains a.o.:

anionic surfactants, non-ionic surfactants, phosphonates

< 5%

DANGER H314- Causes severe skin burns and eve damage. P101- If medical advice is needed, have product container or label at hand. P102- Keep out of reach of children. P280- Wear protective gloves and eye protection. P301+P330+P331- IF SWALLOWED: rinse mouth. Do NOT induce vomiting. P303+P361+P353- IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower]. P305+P351+P338- IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P501- Dispose of contents and container in accordance with all local, regional, national and international regulations. contains a.o.: sodium hydroxide EINECS: 215-185-5, Isotridecanol, ethoxylated EINECS: 500-241-6.

Made in The Netherlands by HG International b.v., Damsluisweg 70, 1332 EJ Almere, The Netherlands, Tel.: +31 36 54 94 700

HG Does what it promises.

UK importer: HG Hagesan (UK) Ltd, Weston Business Centre, Parsonage Road, Takeley, Essex, CM22 6PU. Tel.: +44 (0) 1206 822 744